

2. Tap Assembly

The tap for the Robobrew is fairly straight forward to fit. Make sure the silicon seal is on the tap body prior to installation. (see image below).

The lock nut can be tightened onto the thread from the inside of the Robobrew boiler.

