

Whirlpool Add-On

1. Start by placing the Whirlpool Add-on against the neck of your immersion chiller. The large bend goes at the top, about 1–4 inches from the top of the neck, and the smaller bend goes inside the center of the chiller. The height of the smaller bend does not matter all that much, just as long as the outlet will force the wort onto the chiller coils. This is the important part, as it is the whole reason the whirlpool is able to cool the wort down so fast.
2. Find the spot where the 90 degree bend where the neck of the chiller starts. Mark the placement on the Whirlpool Add-On Assembly.
3. Sitting down, place a folded towel over the top of your leg. Place the Whirlpool Add-On Assembly on the towel, with the mark you made earlier centered on your leg. Make sure the longer of the two bends (the top) is pointing down towards the floor. With one hand on each side of the tube, slowly press down on the copper and bend it until the degree of the bend matches the one in your chiller neck as closely as possible. Use caution, as it is possible to over-bend.
4. Place the newly bent add-on against the neck of your chiller and secure it to the neck with the included zip-ties. Make sure the mark you made matches with the 90 degree bend on the neck of the chiller. Cut off the excess plastic for the zip ties.
5. Use the clamp provided to attach your tubing for recirculation. Tighten with a flat head screwdriver. When finished, your new Whirlpool Immersion Chiller should look something like this. You will now be able to cool faster and reduce the amount of trub going into your fermenter!

