

MoreInstructions[™]

Enoitalia Stainless Stand & Chute

Thank you for your purchase of the Enoitalia Stainless Steel Crusher Destemmer Stand and Chute! We hope this product will provide you with many years of easy reliable service on your home crush pad!

The stand is shipped to you disassembled to save on freight costs, and can be assembled easily in just a few short steps. Before you begin, please ensure you have received all the parts shown below. If you are missing any parts or have any questions, please contact us at 800-823-0010 or info@morewinemaking.com.

Parts Included in the Box

- . Crusher Rest & Chute Assembly x1
- . Stand Side Legs x2
- . Stand Cross Bar x1
- . Bolt x2
- . Nut x2
- . Washer x4

Tools You Will Need

Any combination of two of the following: 13mm or 1/2" Socket, Box Wrench or similarly sized Crescent Wrench. We prefer one socket and one box wrench for easy assembly, but any combo or two of any one tool will do the trick.

Assembly Steps

- 1. Place the Crusher Rest/Chute Assembly on a level surface, upside down.
- 2. Insert the narrow, open ends of the Side Legs onto the stainless dowels on the Chute Assembly. The legs are hand-welded and you may have to flex the end a little bit to get it to fit on.
- 3. Slide a washer onto one of the bolts and insert it through the hole on one end of the Cross Bar.
- 4. Holding the bolt head in place, insert the threaded end upwards through the hole in one of the Side Legs from underneath.
- 5. Place a second washer on the bolt, and then thread the nut in place until it is hand-tight.
- 6. Repeat steps 3-5 with the second bolt and the other end of the Cross Bar.
- 7. Flip the whole Stand & Chute over so that it is standing upright.
- 8. Tighten the nuts in place on the bolts. We suggest you hold the nut on the underside in place with the closed end of a box wrench while tightening the bolt head with a ratchet.







